

Hi-Lo setpoint graphic

After selecting your "Low" decr. set point you can select your "High" incr.set point in the 'increasing set point area'. (vertical above your decr. set point).

e.g. "Low" decr. set point: 10 Bar
"High" incr. set point adjustable between: 13,5- 25 Bar (incr.)

BETA BV
P.O.BOX 1227
2280 CE RIJSWIJK
THE NETHERLANDS

TEL 070 319 97 00
FAX 070 319 97 99

Drawn: mjk	Date: 7-11-2005
Checked:	Date:

Hi-Lo switch